



*Innovative Visualization Method For Demonstrating  
Natural And Enhanced Attenuation*



Grant R. Carey  
Porewater Solutions

SMART Remediation  
Ottawa, ON | February 15, 2018

SMART is  
Powered by:




**VERTEX**  
Environmental Inc.

[www.vertexenvironmental.ca](http://www.vertexenvironmental.ca)


# Visualizing Biodegradation Zones

By Grant R. Carey, Ph.D.



1

## Biogeochemical Processes




### Inorganic Electron Acceptors:

- $O_2$
- $NO_3$
- $Mn_{(s)} \rightarrow Mn^{2+}$
- $Fe_{(s)} \rightarrow Fe^{2+}$
- $SO_4$
- $CO_2 \rightarrow CH_4$

Metabolic Byproducts


2

# TCE Degradation by Redox Zone




3

# Redox Zone Mass Balance at Plattsburgh Air Force Base



Modeled using In-Situ Remediation (ISR-MT3DMS)

Modeled Mass Balance by Redox Zone (t = 40 years)




	CH <sub>4</sub>	SO <sub>4</sub>	Fe/Mn	NO <sub>3</sub>	O <sub>2</sub>
PCE	Green	Green	Green		
TCE	Green	Green	Green		Orange
cis-DCE	Green	Green	Blue		Blue
Vinyl Chloride	Green		Blue		Blue

- Blue: Oxidation (rapid, NO Daughters)
- Green: Reductive Dechlorination (moderate, Daughters, need ED)
- Light Green: Reductive Dechlorination (slow, Daughters, need ED)
- Orange: Cometabolism (rapid if substrate present, NO Daughters)

4


## Main Challenge with MNA and EISB

How do we communicate results??



5

## Example of Redox Zone Delineation




6

# Redox Radial Diagrams

## Section 2.1


7

## Redox Diagram: Electron Acceptors (EA)




8

# Redox Diagram: Metabolic By-Products (MB)




9

# Redox Diagram: Aerobic (Background)




10

# Redox Diagram: Strongly Anaerobic at Well




11

# Redox Zone Transition



12

## Redox Zone Transition



Radial diagrams are ideal for plotting relationships between redox indicators at each monitoring well.

Location	DO (mg/L)	Nitrate (mg/L)	Mn(II) (mg/L)	Fe(II) (mg/L)	Sulfate (mg/L)	Methane (mg/L)
Aerobic	5	10	<0.01	<0.1	25	<0.001
Slightly Anaerobic	0.3	3	0.1	0.3	25	<0.001
Moderately Anaerobic	0.1	<0.01	2	5	18	0.01
Strongly Anaerobic	0.1	<0.01	2	5	2	0.7


13

## VOC Radial Diagrams

14




# VOC Radial Diagram: Source Depletion



15

# Plattsburgh Air Force Base: Plume Attenuation

Carey et al. (2003)



16


# Hill Air Force Base: Plume Attenuation

Carey et al. (1999)

## LEGEND


- Measured analyte concentration exceeds Federal MCL

NOTE: All axes range in concentration from 1 ug/L to 100,000 ug/L and use a log scale.



17

# Wurtsmith Air Force Base, Michigan



## Redox Indicators

- 20 wells
- 5 indicators
- ➔ 100 data points

ES&T, 1996, 30: 3565-3569

### Comparison of $E_h$ and $H_2$ Measurements for Delineating Redox Processes in a Contaminated Aquifer

FRANCIS H. CHAPPELL,<sup>1,2</sup>  
 SHERIDAN K. HAACK,<sup>3</sup>  
 PETER ADRIAENS,<sup>4</sup>  
 MARK A. HENRY,<sup>5</sup> AND  
 PAUL M. BRADLEY<sup>6</sup>

<sup>1</sup>U.S. Geological Survey, 2215 Greenway Road, Suite 220  
 Columbia, South Carolina 29204-0211, U.S. Geological Survey,  
 3029 Massachusetts Way, Suite 5, Lansing, Michigan 48911,  
 Department of Civil & Environmental Engineering,  
 University of Michigan, 241 FREET Building,  
 Ann Arbor, Michigan 48106-2121, and National Center for  
 Integrated Environmental Research,  
 4140 East California Street, Ann Arbor, Michigan 48106


1.18

# Presentation Method #1 – The TABLE

Well	Dissolved Oxygen (mg/L)	Nitrate (mg/L)	Dissolved Iron (mg/L)	Sulfate (mg/L)	Methane (mg/L)
MLS-3A	<0.1	<0.02	18.2	0.8	16.9
MLS-3B	<0.1	0.035	11.5	1.1	6.5
MLS-3C	<0.1	<0.02	9.1	1	3
MLS-3D	<0.1	<0.02	3.1	26	2.2
MLS-3E	0.3	9.37	<0.05	105	0.2
MLS-4A	<0.1	<0.02	15.4	0.8	12.1
MLS-4B	<0.1	<0.02	7.4	30.5	2.5
MLS-4C	0.5	2.49	<0.05	76.5	3.8
MLS-4D	1.8	4.47	<0.05	107	0.4
MLS-5A	<0.1	<0.02	13.3	0.3	13.1
MLS-5B	<0.1	<0.02	12.2	<0.5	4.3
MLS-5C	<0.1	<0.02	12.2	2	7
MLS-5D	0.3	0.032	2.4	150	0.4
MLS-5E	0.6	12.47	<0.05	117	<0.1
MLS-8A	0.3	0.31	3	25	1.7
MLS-8B	0.3	<0.02	20	<0.5	11.7
MLS-8C	0.3	0.082	25	0.7	14.2
MLS-8D	0.3	<0.02	16.3	0.6	16.6
MLS-8E	1.6	25.77	<0.05	97	<0.1
MLS-8F	3.6	11.038	<0.05	112	0.1


1.19

# Presentation Method #2 – Individual Contour Maps




20

# Redox Radial Diagrams



21

# Relative Redox Area Contours




22



# Charleston Naval Weapons Station

Location	Open Well Injection Depth	Sample Date	Dissolved Oxygen (mg/L)	Nitrate (mg/L)	Manganese (mg/L)	Dissolved Iron (mg/L)	Sulfate (mg/L)	Methane (mg/L)
USGS-21	30362	1-8	0.8	0.2	0.2	0	0.2	0.2
USGS-22	30362	1-8	0.8	0.2	0.2	0	0.2	0.2
USGS-23	30362	1-8	0.8	0.2	0.2	0	0.2	0.2
USGS-24	30362	1-8	0.8	0.2	0.2	0	0.2	0.2
USGS-25	30362	1-8	0.8	0.2	0.2	0	0.2	0.2
USGS-26	30362	1-8	0.8	0.2	0.2	0	0.2	0.2
USGS-27	30362	1-8	0.8	0.2	0.2	0	0.2	0.2
USGS-28	30362	1-8	0.8	0.2	0.2	0	0.2	0.2
USGS-29	30362	1-8	0.8	0.2	0.2	0	0.2	0.2
USGS-30	30362	1-8	0.8	0.2	0.2	0	0.2	0.2
USGS-31	30362	1-8	0.8	0.2	0.2	0	0.2	0.2
USGS-32	30362	1-8	0.8	0.2	0.2	0	0.2	0.2
USGS-33	30362	1-8	0.8	0.2	0.2	0	0.2	0.2
USGS-34	30362	1-8	0.8	0.2	0.2	0	0.2	0.2
USGS-35	30362	1-8	0.8	0.2	0.2	0	0.2	0.2
USGS-36	30362	1-8	0.8	0.2	0.2	0	0.2	0.2
USGS-37	30362	1-8	0.8	0.2	0.2	0	0.2	0.2
USGS-38	30362	1-8	0.8	0.2	0.2	0	0.2	0.2
USGS-39	30362	1-8	0.8	0.2	0.2	0	0.2	0.2
USGS-40	30362	1-8	0.8	0.2	0.2	0	0.2	0.2
USGS-41	30362	1-8	0.8	0.2	0.2	0	0.2	0.2
USGS-42	30362	1-8	0.8	0.2	0.2	0	0.2	0.2
USGS-43	30362	1-8	0.8	0.2	0.2	0	0.2	0.2
USGS-44	30362	1-8	0.8	0.2	0.2	0	0.2	0.2
USGS-45	30362	1-8	0.8	0.2	0.2	0	0.2	0.2
USGS-46	30362	1-8	0.8	0.2	0.2	0	0.2	0.2
USGS-47	30362	1-8	0.8	0.2	0.2	0	0.2	0.2
USGS-48	30362	1-8	0.8	0.2	0.2	0	0.2	0.2
USGS-49	30362	1-8	0.8	0.2	0.2	0	0.2	0.2
USGS-50	30362	1-8	0.8	0.2	0.2	0	0.2	0.2
USGS-51	30362	1-8	0.8	0.2	0.2	0	0.2	0.2
USGS-52	30362	1-8	0.8	0.2	0.2	0	0.2	0.2
USGS-53	30362	1-8	0.8	0.2	0.2	0	0.2	0.2
USGS-54	30362	1-8	0.8	0.2	0.2	0	0.2	0.2
USGS-55	30362	1-8	0.8	0.2	0.2	0	0.2	0.2
USGS-56	30362	1-8	0.8	0.2	0.2	0	0.2	0.2
USGS-57	30362	1-8	0.8	0.2	0.2	0	0.2	0.2
USGS-58	30362	1-8	0.8	0.2	0.2	0	0.2	0.2
USGS-59	30362	1-8	0.8	0.2	0.2	0	0.2	0.2
USGS-60	30362	1-8	0.8	0.2	0.2	0	0.2	0.2
USGS-61	30362	1-8	0.8	0.2	0.2	0	0.2	0.2
USGS-62	30362	1-8	0.8	0.2	0.2	0	0.2	0.2
USGS-63	30362	1-8	0.8	0.2	0.2	0	0.2	0.2
USGS-64	30362	1-8	0.8	0.2	0.2	0	0.2	0.2
USGS-65	30362	1-8	0.8	0.2	0.2	0	0.2	0.2
USGS-66	30362	1-8	0.8	0.2	0.2	0	0.2	0.2
USGS-67	30362	1-8	0.8	0.2	0.2	0	0.2	0.2
USGS-68	30362	1-8	0.8	0.2	0.2	0	0.2	0.2
USGS-69	30362	1-8	0.8	0.2	0.2	0	0.2	0.2
USGS-70	30362	1-8	0.8	0.2	0.2	0	0.2	0.2
USGS-71	30362	1-8	0.8	0.2	0.2	0	0.2	0.2
USGS-72	30362	1-8	0.8	0.2	0.2	0	0.2	0.2
USGS-73	30362	1-8	0.8	0.2	0.2	0	0.2	0.2
USGS-74	30362	1-8	0.8	0.2	0.2	0	0.2	0.2
USGS-75	30362	1-8	0.8	0.2	0.2	0	0.2	0.2
USGS-76	30362	1-8	0.8	0.2	0.2	0	0.2	0.2
USGS-77	30362	1-8	0.8	0.2	0.2	0	0.2	0.2
USGS-78	30362	1-8	0.8	0.2	0.2	0	0.2	0.2
USGS-79	30362	1-8	0.8	0.2	0.2	0	0.2	0.2
USGS-80	30362	1-8	0.8	0.2	0.2	0	0.2	0.2
USGS-81	30362	1-8	0.8	0.2	0.2	0	0.2	0.2
USGS-82	30362	1-8	0.8	0.2	0.2	0	0.2	0.2
USGS-83	30362	1-8	0.8	0.2	0.2	0	0.2	0.2
USGS-84	30362	1-8	0.8	0.2	0.2	0	0.2	0.2
USGS-85	30362	1-8	0.8	0.2	0.2	0	0.2	0.2
USGS-86	30362	1-8	0.8	0.2	0.2	0	0.2	0.2
USGS-87	30362	1-8	0.8	0.2	0.2	0	0.2	0.2
USGS-88	30362	1-8	0.8	0.2	0.2	0	0.2	0.2
USGS-89	30362	1-8	0.8	0.2	0.2	0	0.2	0.2
USGS-90	30362	1-8	0.8	0.2	0.2	0	0.2	0.2
USGS-91	30362	1-8	0.8	0.2	0.2	0	0.2	0.2
USGS-92	30362	1-8	0.8	0.2	0.2	0	0.2	0.2
USGS-93	30362	1-8	0.8	0.2	0.2	0	0.2	0.2
USGS-94	30362	1-8	0.8	0.2	0.2	0	0.2	0.2
USGS-95	30362	1-8	0.8	0.2	0.2	0	0.2	0.2
USGS-96	30362	1-8	0.8	0.2	0.2	0	0.2	0.2
USGS-97	30362	1-8	0.8	0.2	0.2	0	0.2	0.2
USGS-98	30362	1-8	0.8	0.2	0.2	0	0.2	0.2
USGS-99	30362	1-8	0.8	0.2	0.2	0	0.2	0.2
USGS-100	30362	1-8	0.8	0.2	0.2	0	0.2	0.2

Average RRA versus time in Pilot Test Area (IWs)



# FREE Visual Bio Software

**Porewater Solutions**  
Expertise • Experience • Innovation

Home Consulting Education Software Support R&D About PWS Contact

Porewater Solutions (PWS) is recognized as an industry leader in modeling consulting services for contaminated sites and water resources, with specialization in litigation and environmental forensics.

The PWS Institute has delivered high quality continuing education to professional engineers and scientists worldwide. We are also proud to be sponsoring the Learning Lab which is being offered for the first time at the 2018 Battelle conference in Palm Springs, California.

PWS offers innovative modeling software tools which are designed to enhance the characterization and remediation of complex sites. Visual Bio is our newest program, offering unique capabilities for visualizing where natural and enhanced attenuation is occurring in groundwater.

PWS invests in a comprehensive Research & Development program to ensure we offer state-of-the-art consulting services, software, and education products. This includes collaborating with university researchers, technology developers, and remediation contractors to evaluate cost-effective remediation strategies at complex sites.

**QUICK LINKS**  
Litigation services  
Expert modeling services

**SOFTWARE**  
Visual Bio  
NMR Depletion Model  
ESR-MT3DMS  
Vapor-2D

**PWS INSTITUTE**  
Online courses  
CRU/POH Registration  
Classroom courses  
Upcoming events

Porewater Solutions, 27 Kingsford Crescent, Ottawa, Ontario, Canada K2K 1T5  
e-mail: info@porewater.com • phone: 613-270-9458 • fax: 613-270-8395

© 2006-2017 Porewater Solutions

www.porewater.com

- User's Guide
- Software
- Plattsburgh AFB examples

Golden Surfer® used for graphics

# Questions



Grant Carey, Ph.D.  
Porewater Solutions

613-270-9458  
[gcarey@porewater.com](mailto:gcarey@porewater.com)  
[www.porewater.com](http://www.porewater.com)